

INSTALLATION INSTRUCTIONS

KATECH GEN V LT BILLET AFM & DI DELETE VALLEY COVER

1. Start with OEM valley cover (1)
2. Remove valley cover screws.
3. Break away OEM valley cover AFM solenoid circuit board. (2, 3)
4. Remove OEM PCV baffle (4)
5. Blue Loctite bolts and install PCV baffle into the Katech cover (5)



1



2



3



4



5



6